

technics	In case of precast concrete panels, gear inclusive.	In case of finished concrete ceiling, gear exclusive.	Name	Reference	Lamp type	A	B	C	D	E
1 cut out			Plasterkit concrete down 120	KR747612	LED directional	□ 252	305	305	200	305
					QT12-ax directional	□ 252	305	305	200	305
					hit-tc-ce directional	□ 252	305	305	230	305
					LED low dir	□ 252	400	400	140	305
			Plasterkit concrete down 40	KR747602	LED	□ or Ø 10	110	110	80	110

2 dimensions	Down 120	Down 40

3 installation	Put the plasterkit through the hole.	Fix the plasterkit with screws.	Fill around perimeter of plasterkit using suitable filler and plaster to hide screws and plasterkit.

4 installation	Minimum filler distance, spread out until zero.	For installing Down 120, see the corresponding installation manual.